

Schuh Promotion Set

Bestehend aus Flex-Running S3 und Freizeitschuh Sneaker II



| Art.-Nr. | VE |
|--------------|----|
| 5988 040 360 | 1 |
| 5988 040 370 | 1 |
| 5988 040 380 | 1 |
| 5988 040 390 | 1 |
| 5988 040 400 | 1 |
| 5988 041 360 | 1 |
| 5988 041 370 | 1 |
| 5988 041 380 | 1 |
| 5988 041 390 | 1 |
| 5988 041 400 | 1 |
| 5988 041 410 | 1 |
| 5988 041 460 | 1 |